


The Schalk radio switching system

compact - convenient - powerful

- ✓ Extremely compact receiver relay for the installation socket
- ✓ 1 to 4 relays available with timer and motor control functions, as well as dimmers and repeaters
- ✓ Hand-held wireless transmitter, build in radio transmitter and push-button available
- ✓ Professional system for unobtrusive installation

- + **Dimming**
Dimmable LED, ESL, incandescent, NV halogen lamps with electronic or wound transformers, HV halogen lamps
- + **Switching**
Lamps, sockets, pond pumps, garage doors, etc.
- + **Controlling**
Louvers, roller shutters, skylights, awnings, etc.



FS3 H2 / FS3 H8 / FS3 HC


Wireless hand-held transmitter

FS3 A1

Pushbutton/radio transmitter

FS3 U4

Flush-mount transmitter



FV2 R

Radio repeater



FE3 S2

Receiver (1 relay)



FE3 D2

Receiver (2 relays)



FE3 Q2

Receiver (4 relays)



FD3 U2

Wireless dimmer

Transmitter

Repeater

Receiver
(selected list)





HC 35
DIN rail-hat clip 35mm



BFS 03
Battery for transmitters

Order details

Item no.	Type	EAN	Description	QR-Info
FD3U29	FD3 U2	4 046929 101301	Radio-controlled universal dimmer 230V AC (FMD) with programmable functions, also for LED/ESL	
FD3U2E9	FD3 U2E	4 046929 101332	Radio-controlled universal dimmer 230V AC (FMD), also for LED/ESL	
FE3D29	FE3 D2	4 046929 101363	Radio-controlled switch, 2 NO, 230V AC (FMD)	
FE3M09	FE3 M (230V AC)	4 046929 101318	Radio-controlled open/close controller 230V AC (FMD), with external control inputs VA/VZ, NA/NZ	
FE3MOK	FE3 M (12-24V DC)	4 046929 101325	Radio-controlled open/close controller 12-24V DC (FMD), with external control inputs VA/VZ, NA/NZ	
FE3Q29	FE3 Q2	4 046929 101349	Radio-controlled switch, 4 relay, 230V AC (FMD)	
FE3S29	FE3 S2	4 046929 101356	Radio-controlled switch, 1 CO. 230V AC (FMD)	
FE3SE2	FE3 SE (12V UC)	4 046929 101295	Radio-controlled switch, 1 ch. 12V UC (FMD), VO	
FE3SE9	FE3 SE (230V AC)	4 046929 101226	Radio-controlled switch, 1 ch. 230V AC (FMD)	
FS3A1B	FS3 A1	4 046929 101257	Surface-mounted transmitter, 1 channel, 3V DC, incl. battery	
FS3H2B	FS3 H2	4 046929 101219	Mini handheld radio transmitter 2 or 4 ch., 3V DC incl. battery	
FS3H8B	FS3 H8	4 046929 101004	Handheld radio transmitter, 8 ch., incl. battery, grey	
FS3HCB	FS3 HC	4 046929 101202	Handheld radio transmitter 32 ch., 3V DC incl. battery, grey	
FS3U41	FS3 U4 (9V DC)	4 046929 101035	Radio transmitter, 4 ch. 9V DC f. batt. op., incl. battery clip (FMD)	
FS3U49	FS3 U4 (230V AC)	4 046929 101011	Radio transmitter, 4 ch. 230V AC (FMD)	
FS3U4V	FS3 U4 (12-24V UC)	4 046929 101028	Radio transmitter, 4 ch. 12-24V UC (FMD)	
MFS109	MFS 1	4 046929 101233	Mini radio control set, consisting of FE3 SE (230V) and FS3 H2	

