



Ventilation/exhaust-fan set to control fume extraction hood





Radio connection set: ZAS F

FV2 E (flush-mount relay) + FV2 SM (window contact-radio transmitter) for monitoring one window Monitoring several windows requires a combination of one FV2 EL and up to four FV2 SM contacts



ATR U2 (flush-mount relay) + MKW 1 (Window contact) for monitoring one window

To monitor several windows, simply switch other MKW1 contacts in parallel





